

Air & Surface Pro XL Set-Up Guide









- SET-UP: Your Air & SurfacePro XL comes with two ActivePure Cells already installed inside the unit. Insert the Power Supply Plug into the power receptacle on the rear of the unit, plug the appropriate cord into the Power Supply and into a working electrical outlet, and turn on your machine. We suggest keeping the Fan on the highest (5th) level setting for at least the first 24-48 hours.
- PLACEMENT: For optimum performance, place the Air & SurfacePro XL countertop or higher in your home or business. If you have a multi-story area, we suggest placing it on the top level. While it will work anywhere, it will be most effective the higher it is we want to work with gravity! NOTE: The rear and top of the unit should always have at least one inch of open area to allow unrestricted airflow.
- SETTING YOUR CONTROLS: Our 24/7 recommended setting is Ion Mode and Fan on the highest (5th) level, but since every environment and every individual is different, you can adjust the fan and ionization setting to what best provides that fresh & crisp feeling and smell in your environment.

